

Instructions

Haley

3-Position Recliner with Central Braking Casters

HPFi



This HPFi recliner was fully assembled in the factory prior to preparing for shipment. The back was removed and placed in the seat for safety in shipping and handling to the site where it will be used.



Step 1. Attach Back to Seat

After carefully removing all components from the packaging, the back can be installed on the two (2) steel “bayonets” on an upright angle in the back of the seat inside the arms. The back should be pushed down onto the bayonets until you hear a “click” of the tabs engaging the bayonets.

Step 2. Attach Back “Flap” to Frame

The flap hanging freely on the outside of the back should pull tightly and be affixed to the hook and loop fastener (aka Velcro) on the inside of the square steel tube cross brace between the two (2) arms of the recliner.

